

JIC: **A320-71-10-00 / 00**

Title: **COWLINGS**

Area:

ATA: **71**

Special Codes:

A/C: **BIS**

Job Instruction Card for - / -

ITEM ONE - COWLINGS

Panels:	none		
Zones:	none		
References:	none		
Material:	MS24665-132	PIN-COTTER	2.0 req.
	MS20392-3C15	PIN	2.0 req.
	AN960-416L	WASHER, FLAT	2.0 req.
	S700M1412-093	LANYARD	1.0 req.
	642-1014-15	BASE	1.0 req.
	642-1014-13	PAD-WEAR	1.0 req.
	642-1014-17	DOUBLER	1.0 req.
	HL11V5-4	PIN	8.0 req.
	NAS1097KE5	RIVET	5.0 req.
	NAS8703U5	SCREW	5.0 req.
	AN960C10	WASHER	5.0 req.
	MS21043-3	NUT	5.0 req.
	642-1014-5	SHIM-HINGE	1.0 req.
	642-1026-503	DOOR ASSY	1.0 req.
	642-1026-11	LUG	1.0 req.
	H2546-1	LATCH	1.0 req.
	HL11V5-3	PIN	4.0 req.
	642-1026-17	HINGE-ASSY	1.0 req.
	HL11V5-6	PIN	5.0 req.
	HL70D5	COLLAR	21.0 req.
	642-1026-7	SHIM-HINGE	1.0 req.
	642-1014-13	PAD-WEAR	1.0 req.
	642-1014-15	BASE	1.0 req.
	642-1014-17	DOUBLER	1.0 req.
	642-1014-5	SHIM-HINGE	1.0 req.
	642-1026-11	LUG	1.0 req.
	642-1026-17	HINGE-ASSY	1.0 req.
	642-1026-503	DOOR ASSY	1.0 req.
	642-1026-7	SHIM-HINGE	1.0 req.
	AN960-416L	WASHER, FLAT	2.0 req.
	AN960C10	WASHER	5.0 req.
	H2546-1	LATCH	1.0 req.
	HL11V5-3	PIN	4.0 req.
	HL11V5-4	PIN	8.0 req.
	HL11V5-6	PIN	5.0 req.
	HL70D5	COLLAR	21.0 req.
	MS20392-3C15	PIN	2.0 req.
	MS21043-3	NUT	5.0 req.
	MS24665-132	PIN-COTTER	2.0 req.
	NAS1097KE5	RIVET	5.0 req.
	NAS8703U5	SCREW	5.0 req.
	S700M1412-093	LANYARD	1.0 req.

PROPERTY OF "ROSSIYA AIRLINES" JSC

JIC: **A320-71-10-00 / 00**

Title: **COWLINGS**

Area:

ATA: **71**

Special Codes:

A/C: **BIS**

Job Instruction Card for - / -

Tools:	RSE1234	ADAPTER	1.0 req.
	RSE1234	ADAPTER	1.0 req.

L/H INLET COWL - FUNCTIONAL CHECK OF PRESSURE RELIEF DOOR.

	MECH	INSP
<p>Do AMM TASK 71-11-00-720-001-A Functional Check of the Pressure Relief Door on the Inlet Cowl.</p> <p>At time of the inspection when the Pressure Relief Door Assembly is opened, inspect the Door Hinge parts for a condition (abnormal wear and tear), verify the Door Hinge Pin is properly secured. In case of finding replace the damaged parts.</p>		

R/H INLET COWL - FUNCTIONAL CHECK OF PRESSURE RELIEF DOOR.

	MECH	INSP
<p>Do AMM TASK 71-11-00-720-001-A Functional Check of the Pressure Relief Door on the Inlet Cowl.</p> <p>At time of the inspection when the Pressure Relief Door Assembly is opened, inspect the Door Hinge parts for a condition (abnormal wear and tear), verify the Door Hinge Pin is properly secured. In case of finding replace the damaged parts.</p>		

PROPERTY OF "ROSSIYA AIRLINES" JSC